


Front Of Audio Rack



Inputs for microphones and/or instruments.



The gain knobs will increase and decrease the input volume of the incoming signal.




Control the volume of the monitors (i.e. speakers). Does not correlate to the gain when recording.

Back Of Audio Rack

Main Power Cord

This is the main power unit. Provides power to the Focusrite Scarlett and the Head Amp 6.



Power cord for Head Amp 6 to power deck.


Power cord for Focusrite Scarlett to power deck.

USB cable that connects audio rack to iMac

Audio output cables that run to the monitors (i.e. speakers).



Audio output from Focusrite Scarlett to Head Amp 6.



Audio input to the Head Amp 6. Receives audio from the Focusrite Scarlett. Allows patrons to connect headphones in front to listen while recording.



Input cables for the drum set. One plugs into Input 3 and the other into Input 4.